

SPI Vehicle Manufacturer specific Pre-OBD 16pin cables

Description	Part No	Image
Citroen (30 pin)	302122V3	
Fiat Lancia Alfa Romeo (3 pin)	30212600	
Ford (2/3pin)	30213000	
GM	30211500	
GM Multec 2 (10 pin)	30211800	
PSA (2 pin)	30211700	
Renault	30212100	
Rover	30211600	
Toyota	30211900	
VAG & Seat (3 x 2 pins) + 12v adapter	30212300	
Volvo	30212000	

Latest Diagnostic Connectors

30216000

SPI – 20 pin Diagnostic Connector for BMW models



30214700

SPI – 14 pin Diagnostic Connector for Mercedes / VW models



30216100

SPI – 38 pin Diagnostic Connector for Mercedes models



ACR4 - For users of the previous generation of Sykes-Pickavant diagnostic equipment, the following accessories continue to be available:

- 30212400 - J1962 16pin Connector
- 30213400 - ACR extension cable
- 302141V2 - Fault Tolerant CAN Bus Cable
- 30214600 - J1962 Universal ISO 16pin cable
- 30214900 - USB / Serial Cable Adaptor
- 30215200 - Uniplex PSA
- 30215300 - Uniplex Land Rover
- 30215400 - Uniplex Volvo
- 30215500 - Uniplex Fiat