


'Valvemaster' Valve Service Centre 03990000


Air-assisted Valve Spring Compressing system

- Allows valve spring and stem seal work, without the need to remove the cylinder head
- Universal Mounting brackets for use on a wide variety of OHC & OHV petrol & diesel engines
- Reversible, multi-position lever arm and precise height adjustment for maximum flexibility
- Supplied on storage panel c/w vinyl overlay & hook / clip set



Contents 03990000

- | | |
|----------|---|
| 03960100 | Adjustable Support Pillars (2) & Beam |
| 03960800 | Lever Arm |
| 03950100 | 502 /504 /505 Valve Spring Adaptors (4) |
| 03965000 | Air Holding Adaptor |
| 03970000 | Valve Stem Seal Pliers |
| 03980000 | Valve Stem Seal Installer Set |
| 67000600 | Telescopic Magnetic Pick-up Tool |



Air Holding Adaptor 03965000

14 / 18mm spark plug port adaptor c/w std airline connection

- Creates cylinder pressure which holds the valve in position whilst the spring is removed



Valve Stem Seal Pliers 03970000

Specially shaped long reach tips shaped for improved grip

- Range from 7mm upwards



Valve Stem Seal Installer Kit 03980000

Set of drive collets and pilots to accurately install valve stem seals without damaging the seal or the spring



Telescopic Magnetic Pick-Up Tool 67000600

To aid in the removal of valve collets - extends up to 490mm

